SPHERO BOLT

ANIMAL BEHAVIOR

BOLT: Animal Behavior
CODE MAT INSTRUCTIONS

# *BOLT: Animal Behavior* Printable Code Mat Instructions

CUT LINE

✂ — — — — — — — — — — — — — — — — — — —

OVERLAP EDGE

– –

**ADHESIVE/ OVERLAP AREA**

///

This 60 page document will be used to assemble your Code Mat. Print out each page on 8.5x11" paper and tape or paste them together using the instructions.

1. Print all 60 pages of the PDF. In the print dialogue box, select "Scale: 100%". This will ensure the Code Mat is printed at the correct size.

The Code Mat can also be printed in Grayscale / Black and White.

# *BOLT: Animal Behavior* Printable Code Mat Instructions

CUT LINE

OVERLAP EDGE

ADHESIVE/ OVERLAP AREA

2. Cut along the solid scissor lines on the top and right sides of each page.

3. Line up the cut edges on the top and right side of the page with the dashed lines on the sheets above and to the right. Pages will overlap on top of eachother.

  • Line up the cut edge on the right side with the vertical dashed line on the page to the right.

 • Line up the cut edge on the top with the horizontal dashed line on the page above it.

6. Tape pages together on the bottom of the Code Mat or glue on the adhesive area so the robot has a smooth surface to roll on.

7. Repeat steps for each page until the Code Mat is assembled.

BOLT: Animal Behavior Printable Code Mat Instructions

Assemble pages in chronological order from left to right.

BOLT: Animal Behavior Printable Code Mat Instructions

Your Code Mat will look like a blank grid with coordinates A-T and 1-10.